

# ME750-VB

**2M LINEAR AMPLIFIER  
LED BARGRAPH FRONTPAGE VERSION  
GU74B**

**M+E**

***Mechanics & Electronics Inc. Hungary***

Draskovits Gábor HALYA Szombathely, Kárpáti K. u. 43. H-9700

e-mail: [halya@chello.hu](mailto:halya@chello.hu)

web: <http://halya.config.hu>

# CONTENT

<b>1.0 General overview.....</b>	<b>2</b>
<b>2.0 Specifications.....</b>	<b>4</b>
<b>3.a Front Panel .....</b>	<b>5</b>
<b>3.b Rear Panel .....</b>	<b>7</b>
<b>4.0 Installation .....</b>	<b>8</b>
<b>5.0 Troubleshooting.....</b>	<b>9</b>
<b>6.0 Drawings .....</b>	<b>11</b>

**ATTENTION!**

**Please read this manual carefully before operating the equipment!**

**The Linear Amplifier is easy to use, and damages can be avoided by following the instructions stated below. Incorrect use may cause the loss of warranty.**

## **1.0 GENERAL OVERVIEW**

The Linear Amplifier is produced by M+E Mechanics & Electronics Inc.

During the design of the ME series, the main point was to construct Linear Amplifiers for HF, VHF, and UHF amateur bands with similar mechanical measures and appearance, using ceramic valves easily available on the market.

The ME750-VB 4 LED bargraph frontpage version utilises the advantages of the ceramic valve, GU74B and considering the power output and price, is a worthy competitor of similar equipment on the market.

The Amplifier are protected by modern circuits, - specially designed and used only by our company, - providing a very high level of protection. With their low input power and high efficiency they fulfil the requirement of an improved amateur station.

To use the Amplifier with satisfaction and utilising all its advantages, please read the following general instructions carefully:

- 1.1 Do not use higher driving power as given in the instruction manual for the  
During SSB transmission the 'MIC GAIN' control of the TCVR is not fit for  
TCVR is regularly activating the protection of the Linear.  
In case of lately designed equipment the output power of the TCVR is  
control of the radio.
- 1.2 The SWR protection of the Linear is inactive during STBY mode.
- 1.3 The required power supply is 230V 50-60Hz according to the EU standard. Verify that the rating of the line fuses located in the rear panel fuse holders is suitable for the AC line voltage you will be using. The fuse should be the glass cartridge slo-blow type. The rating should be 10 Ampere by 230V AC.
- 1.4 The Amplifier is constructed with a forced air cooling. Free air movement has to be provided and considered during positioning.  
Do not operate the Amplifier in excessively warm locations or near heating vents or radiators. Be sure air can circulate freely around and through the Amplifier cabinet, and can provide an unobstructed air inlet for the internal cooling fan. Do not place any books, magazines, manuals, or equipment that will impede the free flow of air near the sides and the hot air exhaust holes located on the top of the cabinet. The internal fan allows an air flow of approximately 150m<sup>3</sup>/hours. The exhaust air becomes quite warm (about 65 C) at high power levels. Do not position any heat-sensitive objects in the exhaust airflow path.

**1.5 The PA is constructed with the following protection circuits and useful features:**

- **Heat up time checking circuit (3min)**
- **Protection circuits (Ia, Ig1, Ig2, SWR>3, overdrive)**
- **Temperature dependent ventilating speed control**
- **Cooling fans (2 pcs)**
- **Function and status indicator leds (6 pcs)**
- **Multifunction LED display (FWD, RFL, Ig1/Ig2, Ia/Ua)**
- **1.5KVA transformer**
- **Built in PS and RF relays**

## 2.0 SPECIFICATIONS

### ME750-VB

<b>Frequency coverage</b>	<b>144-146 MHz</b>	
<b>Operating modes</b>	<b>ALL mode</b>	
<b>Output Power</b>	<b>750 W pep min.</b>	<b>CW/SSB</b>
<b>Driving Power</b>	<b>0-20 W 25 W max.</b>	
<b>Input WSVR</b>	<b>max 1:1.5</b>	
<b>In/Out impedance</b>	<b>50 Ohm</b>	
<b>Valve(s)</b>	<b>GU 74B</b>	
<b>T/R System</b>	<b>opto 12v/8mA appr.</b>	<b>OPEN COLL. OK</b>
<b>Harmonic supression</b>	<b>&gt;50dB</b>	<b>at 600 W out</b>
<b>Intermodulation</b>	<b>&gt;35dB</b>	<b>at 600 W out</b>
<b>Protection</b>	<b>Ia &gt;0.8A</b> <b>Ig1 &gt;10mA</b> <b>Ig 2 &gt;40mA</b> <b>VSWR &gt;3</b> <b>Overdrive &gt;25W</b>	
<b>Dimension</b>	<b>410X185X300 mm</b>	
<b>Weight</b>	<b>24 kg</b>	
<b>Mains</b>	<b>230V/AC 10A, 50/60Hz</b>	

### 3/a FRONT PANEL

1. **POWER ON**

Main switch of the equipment.

2. **ON LED**

The LED indicator glows when the Linear is switched on. Doesn't lit in case the 15V DC - supply for the protection circuits and antenna switch - is missing.

3. **OVR LED**

The blinking LED indicates the active stage of the protection circuit. The protection might be active due to overdrive,  $I_{g1}, I_{g2}$  higher as specified,  $SWR > 2$ , or any other case. (See specifications)

If the protection is active, the TCVR power by-pass the PA. To reset the protection release the STBY switch, then push it again. The reason of the trouble has to be cleared first.

4. **AIR LED**

The indicator glows while transmitting and the T/R relay is switched on. Without driving power the Ip bargraph indicates the idle current of the PA.(100mA)

5. **OPR LED**

Glows when the PA is ready for transmission. During heating up period, when the LED doesn't lit, the driving is blocked. The stby time is  $>120$  sec.

6. **WAIT LED**

Blinking during the heating up period, indicating that the heating is in progress. Required time is  $>120$  sec, when the light goes out and the OPR LED lit up.

7. **QRO LED**

Indicates the high power mode of the PA. Can be activated by the STBY/OPER switch.

8. **OPR/STBY**

The PA can be driven only if this switch is on OPR otherwise the TCVR power by-passes the PA. In case the overload protection is active, release the switch and push it again.

9. **RF FORWARD POWER BARGRAPH**

Indicate RF output power in KW.

**10. REFLECTED POWER BARGRAPH**

Indicate the reflected power in Watts.

**11.  $I_{g1}/I_{g2}$  BARGRAPH**

Indicate grid 1 current, when you push the G2 pushbutton indicate the G2 current in mA.

**12.  $I_p/U_a$  BARGRAPH**

Indicate the  $I_a$  current, when you push the HV pushbutton indicate the  $U_a$  voltage in KV.

**13. TUNE KNOB**

Use for tuning the PA. Tune for max. output power.

### 3/b REAR PANEL

1. **230V**  
Power cord fit for standard 230V-50/60Hz mains. The colour of the protective earth is green/yellow.
2. **230V FUSE**  
Main fuses, 230V. 10A.
3. **FUSE**  
Cathode fuse of the power tubes.
4. **FUSE**  
Fuse for the 18V AC. Value range 1.6A
5. **FAN 1**  
Cooling fan for the main transformer. 12V - 0.2A DC, speed controlled.
6. **FAN 2**  
Cooling fan for the power valves. 12 - 18V/ 0.3A DC. or 230V AC 18W.
7. **PTT**  
Connection for PTT RCA. The relays are closed by earth connection. Low voltage, low current opto entry. Fit for open collector control as well. Use with sequencer if possible.
8. **INP**  
Input connection for the driver TCVR. 50 Ohm.
9. **OUT**  
Aerial connection. 50 Ohm.
10. **GND**  
Ground connection.



## 4.0 INSTALLATION

- 4.1 Connect your TCVR to the Linear using a short, 50 Ohm coaxial cable.
- 4.2 Connect your TCVR ground giving (during transmission ) connector to the *PTT* RCA connector on the rear panel of the Linear, using a screened cable.  
In case your TCVR has an open collector PA controller output, you can use it without difficulties. The input of the PA *PTT* is 15V DC, 10mA.
- 4.3 Connect your aerial to the OUT connector of the Linear. SWR must be better than 1:2.
- 4.4 Using a flexible cable at least 6mm<sup>2</sup>, connect your PA to a suitable grounding point and to the grounding point of the transceiver.
- 4.5 Connect the power cord to the mains and switch on the equipment. The ON led glows and the *WAIT led* start blinking for a period of >120 sec, during the heating period.  
The readiness of the Linear is indicated by the OPR LED. If the PA was out of use for a longer period (2-3 month), it would be advisable to keep the PA heated without driving for a few hours.
- 4.6 When the OPR LED is light push on the OPR switch. The PA is ready to work.
- 4.7 Using the tuning mode of the TCVR (CW) give driving power to reach 200-400 mA indication on the Ip bargraph. Tune for maximal output power with TUNE knob. Increase the driving power until maximum anode current, than carry out fine tuning using the TUNE knob. You can indicate the reflected power on RFL LED bargraph.

**REMEMBER THIS AMPLIFIER DOES NOT REQUIRE MUCH DRIVE POWER. SO START WITH LOW DRIVE POWER, AND THEN TUNE TO RESONANCE AS OUTLINED ABOVE. OTHERWISE, ARCING MAY OCCUR INSIDE YOUR AMPLIFIER.**

**NEVER RUN YOUR AMPLIFIER FOR ANY SUSTAINED PERIOD WITH A SCREEN CURRENT READING GREATER THAN SPECIFIED. IF YOU DO, POSSIBLE DAMAGE AND FAILURE OF THE TUBE WILL RESULT, AND THEY WILL NOT BE COVERED BY WARRANTY!**

- 4.8 Check the g2 current using the Ig2 push-button. Reduce the driving power or make fine tuning in case the grid current would exceed THE SPECIFIED VALUE!
- 4.9 During SSB transmission the peak power of the TCVR may exceed the allowed maximum driving power of the transceiver! Use The *POWER knob* on the TCVR in this case.

## 5.0 TROUBLESHOOTING

Malfunctions are mostly due to improper handling, overload or similar reason.

5.1 Do not use higher input power as stated in the specification. The grid protector circuit will usually safe the power valves, but OVERLOAD alarm will appear regularly. This may happening often in SSB mode, especially in case of old transceivers, when the output power in SSB mode is not adjustable. The 'MIC GAIN' knob is not fit for power reduction!

### 5.2 INPUT SWR

The input SWR of the Linear is better 1:1,5.

A well adjusted TCVR will tolerate these values without any trouble.

### 5.3 OUTPUT SWR

The protection of the Linear will block the transmission in case the SWR of the aerial exceed 1:2.

### 5.4 FAILURES

- The PA not turn on, nothing happens ON switch is pushed.
  - External AC wiring, fuse or circuit breaker may be open.
  - Amplifier power connector not on place - cover safety interlock open.
  - Fuse F1, F2, F4 open or missing - check fuses with an ohmmeter.
- The PA turns ON but no HV is indicated by the multimeter LED bargraph.
  - Possible HV circuit fault.
  - HV fuse on power supply pcb is damaged.
- No base current when you push the PTT (about 100 mA on Ip bargraph).
  - Not Ua, Ug2 or Ug1 voltage. Check the protection resistor on side of RF box,check the fuse on HV board.  
Check fuses on Ug2 and Ug1 board. (Bottom side of PA)Check the stabilizer panels.
- The base current is too low or too high.
  - Check the Ig1 and Ig2 voltage on his PCB boards. (-Ug1 approx. 60V, Ug2 must be 280-300V)
- You can indicate Ip current on Ip bargraph when drive PA but no output power.
  - Check the output coaxial relay.

### 5.5 LIMITED WARRANTY

The M+E *Mechanics & Electronics* will warrant that the equipment will perform substantially in accordance with the written materials for a period of 12 month from the date of receipt and will be free from defects in material and workmanship under normal use. This Limited Warranty is void if failure of the equipment has resulted from accident or misapplication, any kind of modification done, overvoltage, shipping, and in case the damage of the power valves.

Warranty repairs done only on the base of the M+E *Mechanics & Electronics*. Return cost will be covered by the owner.

## 5.6 ALWAYS THINK - SAFETY

**THIS LINEAR AMPLIFIER DESCRIBED IN THIS MANUAL CONTAINS VOLTAGE HAZARDOUS TO HUMAN LIFE AND SAFETY WHICH IS CAPABLE OF INFLICTING PERSONAL INJURY. NEVER OPERATE THE AMPLIFIER WITH THE TOP COVER REMOVED AND THE TOP COVER SAFETY SWITCH DEFEATED. BEFORE REMOVING THE TOP COVER MAKE SURE THE AC LINE POWER CORD HAS BEEN DISCONNECTED FROM THE AC POWER SOURCE. ALLOW A MINIMUM OF 5 MINUTES TO ELAPSE BEFORE REMOVING THE TOP COVER AFTER POWER HAS BEEN REMOVED. THIS IS NECESSARY TO ALLOW THE PLATE VOLTAGE FILTER CAPACITORS TO BLEED DOWN TO A SAFE LEVEL.**

Before operating this unit ensure that the protection conductor (green/yellow wire) is connected to the ground (earth) protective conductor of the power outlet. Do not defeat the protective features of the third protective conductor in the power cord by using a two conductor extension cord or a three-prong/two-prong adapter.

Before operating this unit:

1. Ensure that the instrument is configured to operate on the voltage available at the power source. (See Installation Section)
2. Ensure that the proper fuses are in place in the amplifier's AC line fuse holders located on the rear panel.
3. Ensure that all other devices connected to or in proximity to this amplifier are properly grounded or connected to the protective third-wire earth ground.

If at any time the amplifier shows visible damage, has sustained stress, emits a foul smell, fails to operate satisfactorily, it should not be used until its performance has been checked by qualified service personnel.

Connect a good earth or water pipe ground to the ground post on the rear of the Amplifier. Use the heaviest and shortest connection possible. Before you use a water pipe ground, inspect the connections around your water meter and make sure that no plastic or rubber hose connections are used. These connections interrupt the continuity to the water supply line. Install a jumper around any insulating water connectors you may find. Use heavy copper wire and pipe clamps.

It is best to ground all equipment to one point at the operating position and then ground this point as described above.

## 5.7 SAFETY INTERLOCK SWITCH

While the Amplifier's top cover is in place, the interlock switch closes to allow AC line voltage to reach the power transformer. When the top cover is removed, the interlock switch opens and disconnects the line voltage. This does not discharge the bank of power supply filter capacitors. Be sure to allow the filter capacitors to discharge before you touch anything inside the Amplifier. You can select the High Voltage function of the Multimeter to check the high voltage potential.