

Programming of ME14-X and ME28-X filters

1. Please open the top cover the filter unit.
2. Short with jumper the „PRG” pins on LCD unit.
3. Switch on the filter.
4. You will see on LCD: ATT->write CHNUM
5. Turn the CHANNEL knob up to number of filter inside(12)
6. Push the ATT knob
7. You will see: CHANNEL 1: 28000 (or 14000 in case ME14-X)
8. Push the CHANNEL knob, set the frq of first channel(28040 or 14040) and push the red PRE knob.
9. Push the CHANNEL knob and choose channel 2:
10. Push the CHANNEL knob and set the next channel (28055)
11. Push the red PRE knob to save this channel.
12. Push the CHANNEL knob and choose the next (3) channel.
13. Push the Chanel knob and set the next frq and save it with PRE.
14. Made the described procedure before up to last (12) channel.
15. If you ready push the blue ATT knob to save the program in the PIC.
16. Switch OFF the filter and remove the jumper.
17. Switch ON the filter again.
18. The unit will go to first programmed channel..(28040MHz)
19. With CHANNEL knob you can choose the needed channel.
20. If you push the CHANNEL knob the filter going to „bypass”mode
21. Further info and usage on our webpage